

# Stewart-Amos Sweeper Winterization Tips

---

- Remove blue spin-on water filter canister, empty and leave loose from filter base
- Open in-line ball valve just to the rear of the blue canister to drain water tank
- Remove exit hose from electric water pump and BRIEFLY run pump
- Check water level sight gauge to confirm it has emptied completely, if not charge with air from the top to force out remaining water, replace red top on tube
- Open all in-line ball valves on spray bars and leave open until placed back in service
- Spray penetrating oil into hopper door pin/joint at each open joint, operate door several times and repeat
- Apply penetrating oil to the elevator chains as they slowly rotate
- Turn master electric “kill” switch to off, located driver side front of sweeper near water sight gauge
- Start chassis and sweeper engines every 30 days and let them run 30 minutes at operating temperature
- Check antifreeze for sufficient protection in both systems
- Re-apply penetrating oil to hopper hinge pin at spring start-up